


CROSS antenna.

Transmit / Receive: Horizontal - Vertical - RHCP Schematic



Polarization	Rly1+2+4	Rly3
Horizontal	OFF	OFF
Vertical	OFF	ON
RHCP	ON	OFF